

Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6




Figure 7




Figure 8







Figure 9



FSVR 10

# User Digital Media Input





Figure 11



1110-1

1110-2

1110-3

Figure 12

**fujifilm.net**

Order List | New Order | Image View | Customer Info

### Order List

Name	Number	Size
name1	number1	size1

1202 1204 1206

Delete Process Order Cancel

Pending Orders 3in 4in 5in 8in FD Zip CD-RW Net Other

All Pending Orders All Completed Orders Order Detail

1200



Figure 13.

Quantity: 1 + -

Size: 4X6

Process Cancel

---


to Print

1300

Figure 14

**fujifilm.net** **PMA Las Vegas 1999**

Order List New Order **Image Display** Customer Info

**1402**  **1404**

**Print Setup** **Number of prints.**

**1406** Rotation **1408** Color/Density **1410**

**2**

**Size** **4x6**

**1416** **Reset** **Save** **Apply to All**

**Next** **Remove** **Cancel**


**DSC00001**

**1422** **1424** **1426** **1428**

**Paper Size:** **3** **1** **5** **8** **CD** **JD** **NE** **ZIP** **Other**

**PENDING ORDERS:** **All Pending Orders** **Completed Orders** **Order Detail**

Figure 15




# PMA Las Vegas 1999

Order List

New Order

Image Display

Customer Info



DSC00001

Print Setup

Rotation

Color/Density

90

180

270

Reset



Save

Apply to All

Next

Remove


Cancel



Paper Size: 3 4 5 8 OD FD NET ZIP Other

PENDING ORDERS: All Pending Orders Completed Orders Order Detail

Figure 16




**PMA Las Vegas 1999**

Order List

New Order

Image Display

Customer Info



DSC00001

Print Setup

Rotation

Color/Density

-C

+

C

-M

+

M

-Y

+

Y

-D

+

D

Reset



Save

Apply to All

Next

Remove

Cancel



Paper Size: 3 4 5 8

CD FD NET ZIP Other

ORDERS: All Pending Orders Completed Orders Order Detail



Figure 17

1700

The screenshot shows the Fujifilm.net website interface. At the top is the logo and a navigation bar with links: Order List, New Order, Image View, and Customer Info. The main content area is a form titled 'Customer Info' with the following fields: Status (a dropdown menu currently showing 'Active'), Last Name, First Name, Middle Initial, Address 1, Address 2, City, State, Zip, and Country (pre-filled with 'USA'). Below the form are two buttons: 'Process' and 'Cancel'. At the bottom of the page is a footer section with a 'Pending Orders' link, a row of buttons labeled 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, and a row of buttons labeled 'All Pending Orders', 'All Completed Orders', and 'Order Detail'.

**fujifilm.net**

Order List New Order Image View Customer Info

Status: Active  
Last Name:   
First Name:   
Middle Initial:   
Address 1:   
Address 2:   
City:   
State:   
Zip:   
Country: USA

Process Cancel

Pending Orders

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

All Pending Orders All Completed Orders Order Detail

Figure 18

1802 1804 1806 1808

INPUT DEVICES OUTPUT DEVICES SUPERVISOR OPTIONS USERS

Input Device List

Available Input Devices

BAR CODE READER  
CD-ROM  
DSC (EXIF)  
FLOPPY DISK  
FILM  
JAZ  
MO  
NETWORK  
PC CARD  
SCANNER  
ZIP

1810 1812


Selected Input Devices

ADD  
<Remove  
AddAll>  
<<Clear

RESET DETAILS SET OPTIONS

1800

Figure 19



1900

Figure 20




Figure 21

A screenshot of a graphical user interface dialog box titled "SELECTED INPUT DEVICE". The dialog box has a standard window border with a close button in the top right corner. Inside the dialog, the text "TYPE:" is followed by "FLOPPY DISK". Below this, there are two input fields. The first is labeled "ENTER DEVICE PATH:" and the second is labeled "ENTER KON PATH:". At the bottom of the dialog, there are two buttons: "CANCEL" on the left and "OK" on the right.

2100

Figure 22

1802 1804 1806 1810

INPUT DEVICES OUTPUT DEVICES SUPERVISOR OPTIONS USERS

Output Device List

Available Output Devices

CD WRITER  
FLOPPY DISK  
FRONTIER PRINTER  
JAZ  
MO  
NETWORK  
ZIP

2210

2212

Selected Output Devices

PG3000/4000

Add>  
<Remove  
Add All>  
<<Clear

RESET DETAILS SET OPTIONS

Figure 23

SELECTED OUTPUT DEVICE

TYPE: JAZZ

ENTER DEVICE PREFIX: J101

ENTER COMPANY:

CANCEL OK

2300



[illegible]

2400